Sunflex USA – snakebyte Brand
iDroid:con

Mode & On/Off Button

How To Activate iDroid:con

Gaming (See page 2 for **Game Compatibility Guide**)

LED 1 ON	-	"Mode + X+Y"	**Gamepad mode** (4axis-12 buttons; triggers are digital)
LED 2 ON	-	"Mode + B"	**Mouse mode** (e.g. Angry Birds, touch games)
LED 3 ON	-	"Mode + A"	**Keyboard mode** (e.g. emulators, SNESDroid, Riptide etc.)
LED 1 & 3 ON	-	"Mode + Y"	**iCade mode**
LED 2 & 3 ON	-	"Mode + A+B"	**Keyboard + Mouse mode**

Changing Modes
In order to switch modes you have to deactivate the controller by pressing the **Mode/Power** button until the LEDs turn off.

Selecting Mode
1. Find your preferred mode from the list above
2. Press and hold the **Mode/Power button** and the selected mode (e.g. iCade, hold "Mode + Y")
3. Release buttons when LEDs flash to confirm you have changed to the correct mode
4. Connect/Pair tablet or device via Bluetooth. LEDs will stop blinking and stay lit when connected

Charging

LED4 ON:	Charging
LED4 OFF:	Charged

Future Compatibility
Gamepad mode (5axis - 10 buttons; this means, the triggers are analog)
Currently "Mode + X"

We included the 5axis mode for future compatibility. Analog triggers are much more responsive for racing games.

Pairing
Access your tablet's Bluetooth settings and select "idroid:con" for pairing. Notice the displayed device symbol, the operating system displays the selected mode. Due to Bluetooth 3.0 there is no need for an authorization code (see iCade on iOS, a huge advantage of our controller over the original iCade products).

Turbo
To activate Turbo press and hold the action button you wish to assign this function to and press "Turbo". You will see the controller's main LED flashing whenever you press that programmed button. Press the action button and "Clear" to deactivate Turbo for this button. Turbo is exclusive to both gamepad modes. Turbo does not work with keyboard or mouse emulation.